



HELITE
airbag technology expert



**ZIP'IN 2
AIRBAG**

495€

ZIP'IN 2

Product
description

HELITE
airbag technology expert

NEW DESIGN

- + aeration
- + comfort
- + elegance + discreet
- + tailored cut

INNOVATION

Central zip



2 in 1 VEST
Can be worn **ALONE**
or **UNDER AN**
approved **OUTER**



Helite presents the new Zip'In 2 airbag, a 2 in 1 vest that offers more freedom for riders and better protection. It will appeal to riders who want to combine convenience, style and optimal protection.

New: The more fitted cut and the new shape of the airbag allow a better integration into the jacket, a bigger protection volume at the thorax and a reduction of the cartridge weight. Due to the central zip, the airbag can be worn alone, however it is recommended to wear the Zip'In 2 airbag with an approved outer.

FEATURES

- ◆ Color: Black
- ◆ Stretchy sides for better comfort
- ◆ Breathable mesh on sides and middle back
- ◆ Central zip
- ◆ Highly resistant seams
- ◆ Stretchy water-repellent fabric which does not deform after inflation
- ◆ Compatible with all Helite and Zip'In approved outers



For women and men

Sizes: from Child L to 2XL



Price Zip'In 2 = 495 €*

Compatible with all approved outers

Make sure that your outer is of the same size as your airbag.

**Suggested price with VAT*

ERGONOMICS



COMFORT

ZIP'IN
2

Product
description

HELITE
airbag technology expert

PROTECTION



How to wear the Zip'In 2 airbag

1 ALONE



ALONE

with the central zip closed to the top

Caution: the risk of damaging the airbag in the event of a fall is higher than with an approved jacket.

2 INTEGRATED



INVISIBLE UNDER THE OUTER


Integrated into an approved vest (with or without zip)

Recommended version to avoid damaging the airbag.

SIZE CHART *

ZIP'IN 2 AIRBAG	Child L	XS	S	M	L	XL	2XL
Height (cm)	145-160	150-165	155-170	160-175	165-180	165-185	165-190
Chest line (cm) <i>with clothes</i>	65-80	75-85	80-90	85-95	90-100	95-110	100-115
Waist line (cm) <i>with clothes</i>	55-70	60-75	70-80	75-90	80-95	85-100	95-115
Hip line (cm) <i>with clothes</i>	65-85	75-95	80-100	85-105	90-110	95-120	100-130
Back length (cm)	35-50	40-55	45-60	47-65	50-67	55-70	60-75
Cartridge	50 cc	50 cc	60 cc	60 cc	60 cc	85 cc	85 cc

* This size chart is for information only. Caution, you must not wear Helite airbag if you weigh less than 35kg.



ZIP'IN 2 AIRBAG	Details
Airbag	For an optimal pressure, the airbag volume varies between 17 and 28 liters depending on the size of your airbag. Fast inflation time for an optimal protection -> 0.1 sec. New Zip'In 2: Improvement of the airbag shape for a better integration into the outer and a bigger protection volume at the thorax.
Compatible 	The Zip'In 2 airbag is compatible with several outers: Helite, Dada Sport, Oscar & Gabrielle (indicated by a label). It only takes a few seconds to combine the airbag with the outer.
New Design	New Zip'In 2: A central zip allows to wear the airbag alone, however we recommend to wear it as often as possible with an approved outer.
Saddle Strap	A saddle strap is delivered with each airbag. For safety reasons, more reliability and faster inflation it is important to correctly install and use the saddle attachment. No special tools or technical knowledge are required to install the strap on your saddle.
Reconditioning	Quick and easy replacement of the cartridge. The size of the cartridge is proportional to the size of the airbag. One cartridge is always included with your airbag. We advise you to have an additional cartridge to be replaced quickly after an inflation. New Zip'In 2: reduction of the cartridge weight and new 85 cc cartridge.
Mechanical System	Helite airbags are mechanical to avoid unexpected airbag activation and changing batteries. It is a ready-to-use system that you can reactivate by yourself.
Certification 	CE CERTIFICATION - our airbags are certified by the external laboratory CRITT Sport, the French specialist for objectively testing Personal Protective Equipment (PPE).

The Zip'In label
indicates all the
outers compatible
with our Helite Airbag.



A Can I wear the Zip'In 2 airbag alone?

Yes, this is possible since the airbag is provided with a central zip. However, we recommend wearing it most of the time under an approved outer to avoid damage to the airbag in the event of a fall.

B What are the improvements of the Zip'In 2 airbag?

The Zip'In 2 provides improvements especially in the use and integration of the airbag:

- A central zip has been added to wear the Zip'In 2 alone or with an approved outer (preferred version)
- Improvement of the airbag shape offers a better integration into the outers and a bigger protection volume at the thorax
- Reduction of the cartridge weight for higher comfort

C How can I combine the Zip'In 2 with an outer (vest, jacket, blouson)?

It's simple, just combine the Zip'In 2 airbag with an approved outer (with or without zip). The compatibility is always indicated by the 'Zip'In' label. Caution: the size of the jacket and the Zip'In airbag must be the same. For example, a Zip'In airbag in size M must always be associated with a compatible outer in size M. To know your size, please refer to our size chart. If you hesitate between two sizes, take the bigger size.

D Can I wash the Zip'In 2 airbag?

No, you must not wash your Zip'In airbag in a washing machine or by immersing it in water. We advise you to clean the Zip'In airbag with a soft cloth and soapy water or with babywipes (no detergent, products may alter the fabric). Never put your Zip'In airbag in the tumble drier, on the heater or next to a heat source. When your airbag is clean, store it in a dry place away from moisture.

E Can the airbag activate itself automatically? What happens if I forget to detach myself?

Helite airbags are mechanical to avoid unexpected airbag activation. Accidental deployments are rare. The tractive force required to activate the airbag is between 20 and 30 kg depending on the size. If a rider forgets to detach from his horse, he will feel a strong tension on his jacket before the airbag is triggered. As the car belt, clip and unclip the saddle strap will quickly become a habit.

F Is the airbag reusable?

Yes, as long as the airbag is in good condition (no holes, tears) you can re-use it. Easy to do, you can reset the system yourself in 2 minutes, without sending your vest back to Helite. It is only necessary to replace the cartridge with a new one, available at all Helite dealers worldwide (list on our website www.helite.com). Please, check the size of the airbag when replacing cartridges. If you have any doubt about the correct use of your airbag, our team is at your service.